MATERIAL SAFETY DATA SHEET Use in case of an emergency only (613) 996-6666

Date of Preparation: 12-09-14

SECTION I - PRODUCT AND PREPARATION	INFORMATION						10G15
SCHWARTZ	777 McKay Ro	ad			TRADE NAME	:	HB GOLD CPVC SOLVENT CEMENT; G15 HEAVY BODIED FLOWGUARD GOLD TM
	Pickering, Ontario				MANUFAC. CODE:		10G15
	L1W 3A3 (905)683-0411			PRODUCT CLASS:		ADHESIVE CLASS 3 UN1133 PACKING GROUP II	
	Prepared by: Technical Committee				WHIMIS CLASS:		B D-2
SECTION II - HAZARDOUS INGREDIENTS							
INGREDIENT	CAS NO.	%	NATURE OF HEALTH HAZARD AND ROUTE OF ENTRY	TYPE OF HAZARD	EXPOSURE LIMIT	SOURCE	OTHER HAZARDS
CYCLOHEXANONE TETRAHYDROFURAN CPVC RESIN (Non-Hazardous)	108-94-1 109-99-9 68648-82-8	10-30 40-70 10-30	HARMFUL IF INHALED, IRRITANT SKIN CONTACT HARMFUL IF INHALED, IRRITANT SKIN CONTACT Not Available	ACUTE ACUTE	25 PPM 200 PPM	TLV TLV	
SECTION III - PHYSICAL DATA ODOUR AND APPEARANCE KETONE	PH VALUE		PERCENT VOLATILE BY VOLUME 70%		EVAPORATIO GREATER THA		CETATE
GOLD (YELLOW OXIDE) BOILING POINT 66 °C		VOC LEVEL 490 g/L FREEZING POINT °C			SPECIFIC GRAVITY 1.011		
SECTION IV - FIRE AND EXPLOSION HAZA							
FLAMMABILITY CLASSIFICATION / Class 3, Division 2	FLASHPOINT HAZARDOUS COMBUSTION PRODUCTS -17 °C WHEN FORCED TO BURN, THIS PRODUCT GIVES OUT CARBON MONOXIDE, CARBON DIOXIDE, HYDROGEN CHLORIDE AND SMOKE TAG CUP EXTINGUISHING MEDIA Foam, dry chemical, carbon dioxide or any class B extinguishing agent						
UNUSUAL FIRE AND EXPLOSION HAZARD	s						
							equipment and all other sources of ignition. Keep away from and do rk-proof tools and conductive shoes to avoid sparking hazards.
SPECIAL FIREFIGHTING PROCEDURES							
Exposure to vapours or products of combustion	should be avoided.	Self-cont	tained breathing apparatus is recommended. Vapours ma	ay form an ex	plosive mixture v	with air. Clo	sed containers may rupture when exposed to extreme heat.

Date of Preparation: 12-09-14

MATERIAL SAFETY DATA SHEET Use in case of an emergency only (613) 996-6666

CONTROL OF AND FIRST AND MEASURES	10G
CUTE EFFECTS OF OVEREXPOSURE	EMERGENCY AND FIRST AID PROCEDUES
IHALATION: Excessive exposure to vapours or spray mists can result in headache, dizziness,	INHALATION: Remove victim to fresh air. Restore breathing. Treat symptomatically.
incoordination and loss of consciousness. Irritation of the eyes, nose, throat and lungs	Consult a physician.
can also occur when exposed to high vapour concentrations. Some reports have	SPLASH (EYES): Flush immediately with large amounts of water for at least 15 minutes.
associated repeated and prolonged occupational overexposure to solvents with	Take to a physician for medical treatment. SPLASH (SKIN): Wash affected areas with soap and water. Remove contaminated
permanent nervous system damage. YE CONTACT: This material can cause eye irritation. The effects are usually reversible.	
KIN CONTACT: This material may cause defatting and irritation of skin (Dermatitis) upon prolonged or	clothing. INGESTION: Drink 1 or 2 glasses of water to dilute. DO NOT INDUCE VOMITING.
repeated contact.	Consult a physician or Poison Control center immediately. Treat
IGESTION: Swallowing can cause nausea, vomiting, diarrhea and loss of consciousness.	symptomatically.
SESTION. Swallowing can cause hausea, volitiling, diarried and loss of consciousness.	
HRONIC EFFECTS OF OVEREXPOSURE	IRRITANT SENSITIZER
av	YES: Skin and Eve YES: Skin
ECTION VI - REACTIVITIY DATA	
ABILITY:	HAZARDOUS POLYMERIZATIONS:
ble	Will not occur
ICOMPATABILITY: (Materials to avoid)	CONDITIONS TO AVOID:
xidizing compounds	Vapour concentrations
AZARDOUS DECOMPOSITION PRODUCTS:	Ignition sources
one known	0
CTION VII - SPILL OR LEAK PROCEDURES	
TEPS TO BE TAKEN in case material is Released or Spilled	WASTE DISPOSAL METHOD
estrict access to area. Remove all sources of ignition. Ventilate area. Absorb spill with an absorbent material	Dispose of this material in accordance with Federal, Provincial, and
ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this	Dispose of this material in accordance with Federal, Provincial, and Municipal regulations.
ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup.	
ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup.	
ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup.	Municipal regulations.
ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup.	Municipal regulations. EYE PROTECTION:
ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup. CONTRONT SPECIAL PROTECTION INFORMATION CONTROL PROTECTION EQUIPMENT COTECTIVE GLOVES: hemical reistant gloves made of Viton should be used. Gloves made of nitrile, neoprene or	Municipal regulations.
ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup.	Municipal regulations. EYE PROTECTION: Chemical safety goggles should be worn to prevent eye contact. A face shield may also be necessary.
Ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup. CTION VIII - SPECIAL PROTECTION INFORMATION GRSONAL PROTECTION EQUIPMENT ROTECTIVE GLOVES: hemical reistant gloves made of Viton should be used. Gloves made of nitrile, neoprene or bber may be used for exposure of short duration.	Municipal regulations. EYE PROTECTION: Chemical safety goggles should be worn to prevent eye contact. A face shield may also be necessary. OTHER PROTECTIVE EQUIPMENT:
Ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup. CTION VIII - SPECIAL PROTECTION INFORMATION CREATER COLORING PROTECTION EQUIPMENT ROTECTIVE GLOVES: hemical reistant gloves made of Viton should be used. Gloves made of nitrile, neoprene or bber may be used for exposure of short duration. SPIRATORY PROTECTION:	Municipal regulations. EYE PROTECTION: Chemical safety goggles should be worn to prevent eye contact. A face shield may also be necessary. OTHER PROTECTIVE EQUIPMENT: Eye wash fountain and safety showers must be available in areas where this material is used. Wear protective
ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup. CTION VIII - SPECIAL PROTECTION INFORMATION CRSONAL PROTECTION EQUIPMENT COTECTIVE GLOVES: hemical reistant gloves made of Viton should be used. Gloves made of nitrile, neoprene or bber may be used for exposure of short duration. SPIRATORY PROTECTION: n organic vapour cartridge respiratory mask shall be worn to prevent the inhalation of vapours or spray mist when	Municipal regulations. EYE PROTECTION: Chemical safety goggles should be worn to prevent eye contact. A face shield may also be necessary. OTHER PROTECTIVE EQUIPMENT:
Ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup. CONTRONT SPECIAL PROTECTION INFORMATION CONTROLLED PROTECTION INFORMATION CONTROLLED PROTECTION EQUIPMENT COTECTIVE GLOVES: hemical reistant gloves made of Viton should be used. Gloves made of nitrile, neoprene or bber may be used for exposure of short duration. CONTROLLED CONTROLLED INFORMATION INFORMATION INFORMATION INFORMATION	Municipal regulations. EYE PROTECTION: Chemical safety goggles should be worn to prevent eye contact. A face shield may also be necessary. OTHER PROTECTIVE EQUIPMENT: Eye wash fountain and safety showers must be available in areas where this material is used. Wear protective clothing to prevent skin contact.
Chas vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup. CTION VIII - SPECIAL PROTECTION INFORMATION CRONAL PROTECTION EQUIPMENT COTECTIVE GLOVES: hemical reistant gloves made of Viton should be used. Gloves made of nitrile, neoprene or bber may be used for exposure of short duration. COTECTION PROTECTION: n organic vapour cartridge respiratory mask shall be worn to prevent the inhalation of vapours or spray mist when he TLB or PEL is exceeded. If respiratory protection is required, institute a complete repiratory protection program. lefer to the CSA Standard Z94.4 M1982 "Selection, Care and Use of Respirators" available from the Candadian	Municipal regulations. EYE PROTECTION: Chemical safety goggles should be worn to prevent eye contact. A face shield may also be necessary. OTHER PROTECTIVE EQUIPMENT: Eye wash fountain and safety showers must be available in areas where this material is used. Wear protective clothing to prevent skin contact. ENGINEERING CONTROLS - VENTILATION:
Ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup. CONTRONT SPECIAL PROTECTION INFORMATION CONTROLLED PROTECTION INFORMATION CONTROLLED PROTECTION EQUIPMENT COTECTIVE GLOVES: hemical reistant gloves made of Viton should be used. Gloves made of nitrile, neoprene or bber may be used for exposure of short duration. CONTROLLED CONTROLLED INFORMATION INFORMATION INFORMATION INFORMATION	EYE PROTECTION: Chemical safety goggles should be worn to prevent eye contact. A face shield may also be necessary. OTHER PROTECTIVE EQUIPMENT: Eye wash fountain and safety showers must be available in areas where this material is used. Wear protective clothing to prevent skin contact. ENGINEERING CONTROLS - VENTILATION: General (dilution) ventilation is required during normal use. Local exhaust ventilation may be required during
Chas vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup. CTION VIII - SPECIAL PROTECTION INFORMATION CRONAL PROTECTION EQUIPMENT COTECTIVE GLOVES: hemical reistant gloves made of Viton should be used. Gloves made of nitrile, neoprene or bber may be used for exposure of short duration. COTECTION PROTECTION: n organic vapour cartridge respiratory mask shall be worn to prevent the inhalation of vapours or spray mist when he TLB or PEL is exceeded. If respiratory protection is required, institute a complete repiratory protection program. lefer to the CSA Standard Z94.4 M1982 "Selection, Care and Use of Respirators" available from the Candadian	Municipal regulations. EYE PROTECTION: Chemical safety goggles should be worn to prevent eye contact. A face shield may also be necessary. OTHER PROTECTIVE EQUIPMENT: Eye wash fountain and safety showers must be available in areas where this material is used. Wear protective clothing to prevent skin contact. ENGINEERING CONTROLS - VENTILATION:
Ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup. CTION VIII - SPECIAL PROTECTION INFORMATION RESONAL PROTECTION EQUIPMENT COTECTIVE GLOVES: hemical reistant gloves made of Viton should be used. Gloves made of nitrile, neoprene or ber may be used for exposure of short duration. SPIRATORY PROTECTION: n organic vapour cartridge respiratory mask shall be worn to prevent the inhalation of vapours or spray mist when her TLB or PEL is exceeded. If respiratory protection is required, institute a complete repiratory protection program. tefer to the CSA Standard Z94.4 M1982 "Selection, Care and Use of Respirators" available from the Candadian tandard Association, Rexdale, Ontario. M9W 1R3	EYE PROTECTION: Chemical safety goggles should be worn to prevent eye contact. A face shield may also be necessary. OTHER PROTECTIVE EQUIPMENT: Eye wash fountain and safety showers must be available in areas where this material is used. Wear protective clothing to prevent skin contact. ENGINEERING CONTROLS - VENTILATION: General (dilution) ventilation is required during normal use. Local exhaust ventilation may be required during
Ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup. CTION VIII - SPECIAL PROTECTION INFORMATION RSONAL PROTECTION EQUIPMENT COTECTIVE GLOVES: hemical reistant gloves made of Viton should be used. Gloves made of nitrile, neoprene or bber may be used for exposure of short duration. SPIRATORY PROTECTION: In organic vapour cartridge respiratory mask shall be worn to prevent the inhalation of vapours or spray mist when the TLB or PEL is exceeded. If respiratory protection, Care and Use of Respirators' available from the Candadian tandard Association, Rexdale, Ontario. M9W 1R3 CCTION IX - SPECIAL PRECAUTIONS	Municipal regulations. EYE PROTECTION: Chemical safety goggles should be worn to prevent eye contact. A face shield may also be necessary. OTHER PROTECTIVE EQUIPMENT: Eye wash fountain and safety showers must be available in areas where this material is used. Wear protective clothing to prevent skin contact. ENGINEERING CONTROLS - VENTILATION: General (dilution) ventilation is required during normal use. Local exhaust ventilation may be required during certain operations to keep exposure level below the limit listed in Section II of this data sheet.
Ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup. CTION VIII - SPECIAL PROTECTION INFORMATION RESONAL PROTECTION EQUIPMENT COTECTIVE GLOVES: hemical reistant gloves made of Viton should be used. Gloves made of nitrile, neoprene or bber may be used for exposure of short duration. SPIRATORY PROTECTION: In organic vapour cartridge respiratory mask shall be worn to prevent the inhalation of vapours or spray mist when the TLB or PEL is exceeded. If respiratory protection, Care and Use of Respirators'' available from the Candadian tandard Association, Rexdale, Ontario. M9W 1R3 CTION IX - SPECIAL PRECAUTIONS RECAUTIONS TO BE TAKEN IN HANDLING AND STORING	Municipal regulations. EYE PROTECTION: Chemical safety goggles should be worn to prevent eye contact. A face shield may also be necessary. OTHER PROTECTIVE EQUIPMENT: Eye wash fountain and safety showers must be available in areas where this material is used. Wear protective clothing to prevent skin contact. ENGINEERING CONTROLS - VENTILATION: General (dilution) ventilation is required during normal use. Local exhaust ventilation may be required during certain operations to keep exposure level below the limit listed in Section II of this data sheet.
ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup.	EYE PROTECTION: Chemical safety goggles should be worn to prevent eye contact. A face shield may also be necessary. OTHER PROTECTIVE EQUIPMENT: Eye wash fountain and safety showers must be available in areas where this material is used. Wear protective clothing to prevent skin contact. ENGINEERING CONTROLS - VENTILATION: General (dilution) ventilation is required during normal use. Local exhaust ventilation may be required during certain operations to keep exposure level below the limit listed in Section II of this data sheet. OTHER PRECAUTIONS Protect sunlight and away
ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup.	Municipal regulations. EYE PROTECTION: Chemical safety goggles should be worn to prevent eye contact. A face shield may also be necessary. OTHER PROTECTIVE EQUIPMENT: Eye wash fountain and safety showers must be available in areas where this material is used. Wear protective clothing to prevent skin contact. ENGINEERING CONTROLS - VENTILATION: General (dilution) ventilation is required during normal use. Local exhaust ventilation may be required during certain operations to keep exposure level below the limit listed in Section II of this data sheet. OTHER PRECAUTIONS ect sunlight and away non-sparking.
Ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup. CTION VIII - SPECIAL PROTECTION INFORMATION CRESONAL PROTECTION EQUIPMENT COTECTIVE GLOVES: hemical reistant gloves made of Viton should be used. Gloves made of nitrile, neoprene or bber may be used for exposure of short duration. SPIRATORY PROTECTION: n organic vapour cartridge respiratory mask shall be worn to prevent the inhalation of vapours or spray mist when her TLB or PEL is exceeded. If respiratory protection is required, institute a complete repiratory protection program. Hefer to the CSA Standard 294.4 M1982 "Selection, Care and Use of Respirators" available from the Candadian tandard Association, Rexdale, Ontario. M9W 1R3 CTION IX - SPECIAL PRECAUTIONS ECAUTIONS TO BE TAKEN IN HANDLING AND STORING TORAGE: Keep storage area separate from populated work areas. Store in a cool, dry, well ventilated area, out of dire from incompatible materials and any source of ignition. Ventilation fans and electrical equipment should be ANDLING: Avoid prolonged or repeated inhalation of vapours or spray mist. Avoid prolonged or repeated skin contact	Municipal regulations. EYE PROTECTION: Chemical safety goggles should be worn to prevent eye contact. A face shield may also be necessary. OTHER PROTECTIVE EQUIPMENT: Eye wash fountain and safety showers must be available in areas where this material is used. Wear protective clothing to prevent skin contact. ENGINEERING CONTROLS - VENTILATION: General (dilution) ventilation is required during normal use. Local exhaust ventilation may be required during certain operations to keep exposure level below the limit listed in Section II of this data sheet. OTHER PRECAUTIONS ect sunlight and away non-sparking.
ch as vermiculite or sand and place material into a closed container. If a large spill, dike area to prevent this aterial from entering water systems or sewers. Wear protective equipment during cleanup.	Municipal regulations. EYE PROTECTION: Chemical safety goggles should be worn to prevent eye contact. A face shield may also be necessary. OTHER PROTECTIVE EQUIPMENT: Eye wash fountain and safety showers must be available in areas where this material is used. Wear protective clothing to prevent skin contact. ENGINEERING CONTROLS - VENTILATION: General (dilution) ventilation is required during normal use. Local exhaust ventilation may be required during certain operations to keep exposure level below the limit listed in Section II of this data sheet. OTHER PRECAUTIONS rect sunlight and away non-sparking. t. Ground and bond