

HS 10 SHEEN CLEAR LACQUER

PRODUCT CODE:

1C369 HS 10 Sheen Clear Lacquer

PHYSICAL PROPERTIES:

Viscosity:	24 - 27 sec #4 Ford Cup
Flash Point:	5°C
Weight Solids:	26 to 30%
Density:	0.944 g/ml
Sheen:	10 (Flat)
Appearance:	cloudy liquid
Shelf Life:	2 years unopened

PRODUCT DESCRIPTION AND USES:

Schwartz HS 10 Sheen Clear Lacquer is a high solids nitrocellulose-based lacquer topcoat for any interior wood furniture and cabinetry. It has an excellent adhesion and film build providing protection and aesthetics to any wood surface.

PRODUCT ADVANTAGES:

1. Fast dry
2. Excellent build
3. Accents wood grain
4. High solids

ENVIRONMENTAL INFORMATION:

VOC: max 699 g/L

APPLICATION DATA:

Suggested Uses:	Used for interior wood furniture and millwork
Mixing Instructions:	Mix before use. 1C369 is ready for use. If reduction is needed, reduce with 4T100 Lacquer Thinner to adjust spray viscosity
Pot Life:	NA
Recommended System:	Use Schwartz 1C189 HS Sanding Sealer, followed by 1C369 HS 10 Sheen Clear Lacquer
Application Tools:	Apply using conventional, airless, air-assisted airless and HVLP sprayer/atomizer
Coverage:	400 ft ² /gal
Reducer:	4T100 Lacquer Thinner
Retarder:	4T175 Lacquer Retarder
Clean-up Solvent:	4T100 Lacquer Thinner

DIRECTIONS FOR USE:

Surface Preparation: Surfaces must be clean, dry and contaminant-free. Sand wood with 150-grit sandpaper before staining or coating. Remove all dust. When sealer or topcoat is sanded, always apply succeeding coat within 8 hours of sanding. Sand between coats with 280-320 grit sandpaper.

Ambient Conditions: Use only when ambient conditions are 18°C to 30°C and RH= 40-60%. Wood moisture content must be between 6 - 10%

Application: Following surface preparation; Apply by spray. Check with equipment manufacturer for settings to achieve the correct atomization. For best results, seal bare wood with 1 coat of 1C189 HS Sanding Sealer followed by 2 even coats of 1C369 HS 10 Sheen Clear Lacquer at 3-5 mils wet film thickness per coat. Always allow to dry and scuff sand between coats with 280-320 grit sandpaper. Film build of entire system must not exceed 5 mils dry film thickness.

Dry Time:

Tack free in 15 minutes (25C, 60% RH)

Dry Hard in 30-45 mins. (25C, 60% RH).

CAUTION: Cold temperature, high humidity, or lack of airflow will prolong dry times.

Recoat time: 30-45 minutes (25C, 60% RH)

Clean-up: 4T100 Lacquer Thinner

Storage: Store indoor at room temperature, away from heat, ignition sources, open flames and direct sunlight.

Warning: Use in a well-ventilated area. AVOID sparking, use non-sparking tools. Avoid open flames, turn off all pilot lights, ensure that work area is properly ventilated. Soiled rags and waste products may contain combustible liquids or vapours, dispose in accordance with local regulations. Refer to MSDS for information on safe use of this product.

LIMITATIONS and WARRANTY

The recommendations made and the information herein is based on our own and independent laboratory experience, and is believed to be accurate under controlled conditions. However, no warranty or guarantee of accuracy is made because we cannot cover every possible application of product nor anticipate every variation encountered in weather conditions, job- conditions, methods used and types of surfaces on which the product is applied. The users shall make their own tests to determine the suitability of such products for any particular purpose. Schwartz makes no warranties with respect to this product, expressed or implied, without limitation, the implied warranties of merchantability or fitness for a particular purpose.

Schwartz liability shall be limited in all events to supplying sufficient product to re-treat and/or repair the specific area to which Schwartz product has been applied. Schwartz reserves the right to have the true cause of any difficulty determined by accepted test methods. Schwartz shall have no other liability, including liability for incidental, consequential or resultant damages, however caused, whether due to breach of warranty, negligence, or strict liability.

THIS WARRANTY MAY NOT BE MODIFIED OR EXTENDED BY REPRESENTATIVES OF SCHWARTZ, ITS DISTRIBUTORS OR DEALERS.